# Quick disconnect couplings DN 19

Art. No. 141561 to 141575

P 5-123 e

one side

#### »R39MS« series

Single-sided blocking and quick connect coupling with extremely high flow performance. To prevent injuries or a "whiplash" effect, we recommend that the plug-in nipple is held with one hand during uncoupling.

These quick disconnect couplings are not suitable for direct attachment to pulsating tools. We recommend using our vibration dampers, according to ISO 6150 § 7.1.

Areas of application: Machine and plant engineering, manufacturing industry, workshops.

 $\begin{array}{lll} \text{Operating pressure} & 0 - 35 \text{ bar} \\ \text{Medium temperature} & -20 ^{\circ}\text{C to } 100 ^{\circ}\text{C} \\ \text{Ambient temperature} & -20 ^{\circ}\text{C to } 100 ^{\circ}\text{C} \\ \text{Flow rate} & 8700 \text{ l/min (air)} \\ \end{array}$ 

Flow rate measurement at 6 bar and  $\Delta p$  = 0.5 bar Housing Brass with a bare metal surface Valve Brass with a bare metal surface

Spring Stainless steel

Sleeve Brass with a bare metal surface
Threaded piece Brass with a bare metal surface

Sealant NBR

Quick disconnect coupling DN 19, brass with a bare metal surface, male				
Art. No.	Type No.	Connection	Length	a/f
			mm	mm
141561	419.14	G 3/4 ET	95.0	41
141562	419.15	G 1 ET	98.0	41
141563	419.16	G 1 1/4 ET	98.0	42

Quick disconnect coupling DN 19, brass with a bare metal surface, female				
Art. No.	Type No.	Connection	Length	a/f
			mm	mm
141564	419.04	G 3/4 IT	98.0	41
141565	419.05	G 1 IT	100.0	41
141566	419.06	G 1 1/4 IT	102.0	50


Quick disconnect coupling DN 19, brass with a bare metal surface, with hose stem				
Art. No.	Type No.	Connection	Length	a/f
			mm	mm
141567	419.26	Stem, I.D. 16	114.0	41
141568	419.27	Stem, I.D. 19	114.0	41
141569	419.28	Stem, I.D. 25	114.0	41


RIEGLER & Co. KG, eDocumentation Schützenstraße 27 | 72574 Bad Urach Tel. +497125 9497-41 | -260 | -620 eDocumentation@riegler.de Edition 02/2024


# P 5-123 e

# Quick disconnect couplings DN 19 Art. No. 141561 to 141575
















419.05





Stem for couplings DN 19, brass with a bare metal surface				
Art. No.	Type No.	Description	Length mm	
141576	419.76	Stem, I.D. 16	75.0	
141577	419.77	Stem, I.D. 19	75.0	
142170	419.78	Stem, I.D. 25	75.0	

Plug for couplings DN 19, brass with a bare metal surface, male				
Art. No.	Type No.	Description	Length	a/f
Art. No.	Type No.	Description	mm	mm
141570	419.64	Plug, G 3/4 ET	60.0	30
141571	419.65	Plug, G 1 ET	65.0	35
141572	419.66	Plug, G 1 1/4 ET	68.0	46

Plug for couplings DN 19, brass with a bare metal surface, female				
Art. No.	Type No.	Description	Length	a/f
			mm	mm
141573	419.54	Plug, G 3/4 IT	58.0	32
141574	419.55	Plug, G 1 IT	68.0	41
141575	419.56	Plug, G 1 1/4 IT	70.0	50













#### P 5-123 e

# Quick disconnect couplings DN 19

Art. No. 141561 to 141575



#### Installation location

The installation location of the quick-connect coupling must be selected so that the health of the person operating it cannot be harmed by sources of danger in the immediate surroundings, e.g. from slipping, jamming, contaminating or burning.

## Low pressure applications

Threads for low-pressure applications are, if seriesrelated no corresponding coatings or sealing rings are present, to be provided with suitable sealing materials, such as a PTFE belt or liquid sealing agent. Here the resistance to the flowing medium must be paid attention to.

#### Service manual

Quick-connect couplings are predominantly maintenance-free, if used in standard applications and handled carefully. The selection of the quick-connect coupling must be compatible with the intended purpose of use and material. Depending on the operating conditions it is recommended to provide the following points during maintenance:

**External visual inspection** with dirt in the functioning area of coupling and plug (seal area, control elements) these must be cleaned. The following distinguishing symptoms require replacement of the corresponding parts: Torn, damaged, heavily damaged or corroded parts, leaks on coupling and / or plug parts.

**Function test** under maximum Max. operating pressure can be used to test the quick-connect coupling for possible malfunctions and leaks. During the testing and operating phase it must be ensured that the operating personnel work protected.


Replacement intervals for quick-connect couplings must, if available, be adapted to the state or technical standards. However, also operating experiential values, which result from the required operational safety and the conditions of use, such as downtimes, coupling frequency, Max. operating pressure and properties of the medium, are critical for establishing the replacement intervals.

# **Pulsating tool**

When using pulsating tools it is recommended to observe the standard ISO 6150, § 7.1. It recommends installing a minimum 300 mm long, flexible hose between the pulsating tool and the quick-connect coupling. The oscillating forces are taken by the hose piece and thus increase the service life of the quick-connect coupling. No warranty can be made for couplings mounted directly on pulsating tools.

#### Flow direction

The recommended flow direction is from the coupling to the plug if nothing else is specified in the technical data sheet.



## Application with hoses

When using hoses the permissible Max. operating pressure and the working temperature must absolutely be observed and suitable hose connections must be seen to.